

Internal & Surrogate Standard Solutions for Discrete Vial VOC Auto-samplers

standard smart



Diluting internal and surrogate standard solutions from concentrates for your discrete vial VOC auto-sampler is costly and time consuming. These types of auto-samplers usually have 5 ml reservoirs for internal standard and surrogate solutions. With **o2si's standard smart**, diluting standards is no longer necessary. Internal and surrogate **standard smart** solutions can be purchased in a 5 ml ampule at working concentrations. To refill the internal and surrogate standard reservoir, analysts simply open an ampule and pour. This increases productivity, eliminates dilution errors, reduces paperwork and dilution tracking, and reduces contamination problems.

Provides Significant Cost Savings:

- Increases Productivity
- Eliminates Dilution Errors
- Reduces Paperwork and Dilution Tracking
- Reduces Contamination Problems

o2si
smart solutions

Contact Daniel R. Biggerstaff, Ph.D.
(843) 763-4884
P.O. Box 30712 • Charleston, SC 29417
www.o2si.com

o2si is an ISO 9001 certified company.

